

NTK | COCAINE FIELD USE SUMMARY & COLOR CHART

VERSION 1.0 - IABS ©2015 - www.s2detect.com

**AFTER APPLYING SUBSTANCE TO NEW TEST STRIP,
COMPARE RESULTS WITH COLOR INDICATIONS BELOW.**

NEGATIVE RESULTS —



TEST ZONE →

NEW STRIP



+ **POSITIVE RESULTS**



POSITIVE RESULTS:
Intense solid, bright blue.

1. Remove test strip and swab from packaging.
2. Identify location of suspect residue. Insert swab into residue.
3. Rub and mix swab through residue for 5-10 seconds and ensure sample is embedded in swab tip. Dab swab onto strip test zone for 5 sec.
4. Positive color indication will be an intense solid bright blue.
5. Time for positive indication: Cocaine HCL - Rapid/instant/less than 2 seconds. Cocaine free base - Slow 15 second color development.
6. If no color indication observed after 20 seconds, suspect residue is unlikely to contain detectable material.
7. If positive, immediately take photographic evidence of test strip. Document time, date, location on reverse of test strip. Initiate relevant security plan.
8. Note: Some of test zone reagents may be removed into swab tip during dab/rub. This is NOT a positive reaction. Please check swab tip for positive color indication.