

NTK | HEROIN FIELD USE SUMMARY & COLOR CHART

VERSION 1.0 - IABS ©2015 - www.s2detect.com

**AFTER APPLYING SUBSTANCE TO NEW TEST STRIP,
COMPARE RESULTS WITH COLOR INDICATIONS BELOW.**

**NEGATIVE
RESULTS** —

NTK
HEROIN
Hold
Here



NEGATIVE
RESULTS
ON SWAB

TEST
ZONE

NEW
STRIP

NTK
HEROIN
Hold
Here



+

**POSITIVE
RESULTS**

NTK
HEROIN
Hold
Here



POSITIVE
RESULTS:
DARK BLACK
ON SWAB

1. Remove test strip and swab from packaging.
2. Identify location of suspect residue. Insert supplied swab into residue.
3. Rub swab through residue for 5-10 seconds and ensure sample is embedded in swab tip. Rub swab on strip test zone for 5 seconds.
4. Positive color indications: Solid black color on swab.
5. Time for positive indication: Rapid/instant/less than 2 seconds.
6. If no color indication observed after 10 seconds, suspect residue is unlikely to contain detectable heroin residue.
7. If positive, immediately take photographic evidence of test strip. Document time, date, location on reverse of test strip. Initiate relevant security plan.
8. Note: Some of test zone reagents may be removed into swab tip during rub. This is NOT a positive reaction. Please check swab tip for positive color indication.